



How big is it?

Below is a guide to the maximum laptop dimensions for each Crumpler bag!

Product	Length	Width	Thickness	Length	Width	Thickness
	Inches			Centimetres		
Base Toucher	10.5	15	2	26.67	38.1	5.08
Cheesy Disco	13.5	11	2	34.29	27.94	5.08
Crippy Duck	10	14	2	25.4	35.56	5.08
Double Charge	11	13	2	27.94	33.02	5.08
December Quarter	15.5	11.5	2	39.37	29.21	5.08
Farmers Double	11	15.5	2	27.94	39.37	5.08
McBains (M)	10.5	10	2	26.67	25.4	5.08
McBains (L)	12	11	2	30.48	27.94	5.08
McBains (XL)	14	12	2	35.56	30.48	5.08
Roll O Notes	12	10	2	30.48	25.4	5.08
Sheep Scarer	10	13	2	25.4	33.02	5.08
Sticky Date	16	11	2	40.64	27.94	5.08
Team Player	11.5	15.5	2	29.21	39.37	5.08
The Formal Lounge	10	14	2	25.4	35.56	5.08
The Puppet	9.5	12.5	2	24.13	31.75	5.08
Very Busy Man	14	11	2	35.56	27.94	5.08
Wack O Phone	13	13	2	33.02	33.02	5.08
Wee Bee	9	11.5	2	22.86	29.21	5.08